

# Screw Total Positional Error at Scale Positions

All values are inches

Note: Back error and Backlash error is impacted by screw backlash plus mechanical linkage since scale is not directly at screw/nut

Error size Relative to Scale Position

Scale Position (points every 0.1")

Screw Forward Error    Screw Back Error    Backlash Error

