

		TSVB-PA and TSVB-PB are not supported.
coding	Signal types A, B, Z differential output, Z signal open collector output	
device information		
Low the number	Frequency division ratio	Incremental: TSVB-PB - 1:1; TSVB-PA - configurable through parameter PA78; Absolute value: configurable through parameter PA78;
out		
Location	input frequency	Low-speed pulse command port: differential input $\leq 500\text{kpps}$, single-ended input $\leq 200\text{kpps}$; High-speed pulse command port: differential input $\leq 4\text{Mpps}$;
	command mode	Direction + pulse sequence; CW + CCW pulse sequence; two-phase A/B quadrature pulse; internal position command;
	Electronic gear ratio	Numerator: 1~32767; Denominator: 1~32767;
speed	Analog command input support, -10~+10V input	
	Command acceleration and deceleration parameter settings	
	Command source: internal speed command, analog command	